


1 2 3 4 5 6	HEAD1	1 2 3 4 5 6	HEAD11
1 2 3 4 5 6	HEAD2	1 2 3 4 5 6	HEAD12
1 2 3 4 5 6	HEAD3	1 2 3 4 5 6	HEAD13
1 2 3 4 5 6	HEAD4	1 2 3 4 5 6	HEAD14
1 2 3 4 5 6	HEAD5	1 2 3 4 5 6	HEAD15
1 2 3 4 5 6	HEAD6	1 2 3 4 5 6	HEAD16
1 2 3 4 5 6	HEAD7	1 2 3 4 5 6	HEAD17
1 2 3 4 5 6	HEAD8	1 2 3 4 5 6	HEAD18
1 2 3 4 5 6	HEAD9	1 2 3 4 5 6	HEAD19
1 2 3 4 5 6	HEAD10	1 2 3 4 5 6	HEAD20



PRINTEX UE				JOB NO.	DW
				1	
DR	PM	CHK	PM	APP	PM
NAME				NOUVO/SPECTRUM	
NAME HEAD INPUTS & OUTPUTS					
SCALE	B	DR	NO	DWGSE	DR
					07